

# Part 573 Safety Recall Report

# 18V-611

**Manufacturer Name :** Coach and Equipment Mfg Corp.

**Submission Date :** SEP 11, 2018

**NHTSA Recall No. :** 18V-611

**Manufacturer Recall No. :** NR



## Manufacturer Information :

## Population :

**Manufacturer Name :** Coach and Equipment Mfg Corp.

**Number of potentially involved :** 121

**Address :** 130 Horizon Park Drive

**Estimated percentage with defect :** NR

**Penn Yan NY 14527**

**Company phone :** 1-800-724-8464

## Vehicle Information :

**Vehicle 1 :** 2013-2014 Coach and Equipment Condor LT

**Vehicle Type :** BUSES, MEDIUM & HEAVY VEHICLES

**Body Style :** OTHER

**Power Train :** DIESEL

**Descriptive Information :** Ricon Corporation supplied a list of wheelchair lift serial numbers and purchase order numbers.  
The concerned vehicles are installed with a Ricon S or K series Titanium wheelchair lifts.

**Production Dates :** JAN 01, 2013 - DEC 31, 2014

**VIN Range 1 : Begin :** NR **End :** NR

Not sequential

**Vehicle 2 :** 2013-2017 Coach and Equipment Phoenix

**Vehicle Type :** BUSES, MEDIUM & HEAVY VEHICLES

**Body Style :** OTHER

**Power Train :** GAS

**Descriptive Information :** Ricon Corporation sent a list of serial numbers and purchase orders for the concerned wheelchair lifts.  
The concerned vehicles are installed with a Ricon S or K series Titanium wheelchair lift.

**Production Dates :** JAN 01, 2013 - DEC 31, 2017

**VIN Range 1 : Begin :** NR **End :** NR

Not sequential

**Vehicle 3 :** 2015-2015 Coach and Equipment Pegasus

**Vehicle Type :** BUSES, MEDIUM & HEAVY VEHICLES

**Body Style :** OTHER

**Power Train :** DIESEL

**Descriptive Information :** Ricon supplied a list of lift serial numbers and purchase order numbers of the concerned wheel chair lifts.

The concerned vehicles are installed with a Ricon S or K series Titanium wheel chair lift.

Production Dates : JAN 01, 2015 - DEC 31, 2015

VIN Range 1 : Begin :

NR

End : NR

Not sequential

Vehicle 4 : 2013-2017 Coach and Equipment Metro Lite

Vehicle Type : BUSES, MEDIUM & HEAVY VEHICLES

Body Style : OTHER

Power Train : GAS

Descriptive Information : Ricon Corporation sent a list of serial numbers and purchase orders for the concerned wheelchair lifts.

The concerned vehicles are installed with a Ricon S or K series Titanium wheelchair lift.

Production Dates : JAN 01, 2013 - DEC 31, 2017

VIN Range 1 : Begin :

NR

End : NR

Not sequential

## Description of Defect :

Description of the Defect : These vehicles have a Ricon Titanium wheelchair lift installed. If the wheelchair lift position input cam fails and the lift operator continues to press the "up" button on the operating pendant while the lift is occupied, the cutoff switch is disabled and the platform can travel past the vehicle floor height, potentially causing the occupant to tip inwards, toward the vehicle.

FMVSS 1 : NR

FMVSS 2 : NR

Description of the Safety Risk : Potentially the person on the lift platform being lifted can be tipped inward, towards the inside of the vehicle.

Description of the Cause : The position input cam fails and the lift operator continues to press the "up" button on the operation pendant.

Identification of Any Warning that can Occur : The occupied lift platform when moving upward will start to rise past the vehicle floor height

## Supplier Identification :

### Component Manufacturer

Name : Ricon Corporation

Address : 1135 Aviation Place

San Fernando CALIFORNIA 91340

Country : United States

**Chronology :**

We received a Safety Recall Notice (18E-044) from the Ricon Corporation.

**Description of Remedy :**

**Description of Remedy Program :** The owners / operators are to contact the Ricon Corporation to arrange for service at the nearest Ricon servicing dealer. Ricon will provide materials and labor through their authorized Ricon dealers

**How Remedy Component Differs from Recalled Component :** The input cam will not allow the cutoff switch to be disabled, keeping the platform from raising above floor level if the "up" button on the operating pendant is being pressed.

**Identify How/When Recall Condition was Corrected in Production :** Ricon stopped releasing wheelchair lifts until they resolved the issue.

**Recall Schedule :**

**Description of Recall Schedule :** Recall letters will be sent to dealers and end users.

**Planned Dealer Notification Date :** SEP 17, 2018 - SEP 24, 2018

**Planned Owner Notification Date :** SEP 17, 2018 - SEP 24, 2018

\* NR - Not Reported