

# Part 573 Safety Recall Report

# 19V-160

**Manufacturer Name :** Supreme Corporation

**Submission Date :** MAR 01, 2019

**NHTSA Recall No. :** 19V-160

**Manufacturer Recall No. :** NR



## Manufacturer Information :

**Manufacturer Name :** Supreme Corporation

**Address :** 2581 East Kercher Road

Goshen IN 46528

**Company phone :** 999

## Population :

**Number of potentially involved :** 20

**Estimated percentage with defect :** 100 %

## Vehicle Information :

**Vehicle 1 :** 2014-2016 Supreme Classic American Trolley

**Vehicle Type :** BUSES, MEDIUM & HEAVY VEHICLES

**Body Style :** OTHER

**Power Train :** DIESEL

**Descriptive Information :** Supreme Classic American Trolleys equipped with certain Ricon S-Series and K-Series Titanium wheel chair lifts that are subject to Ricon recall 18E-044.

**Production Dates :** MAY 01, 2015 - DEC 30, 2016

**VIN Range 1 : Begin :**

NR

**End :** NR

Not sequential

## Description of Defect :

**Description of the Defect :** Certain Supreme Classic American Trolleys were equipped with Ricon Corporation S-Series or K Series Wheelchair Lifts that are subject to Ricon Recall 18E-044. According to Ricon, the lift positioning input cam may fail while the lift is in use.

**FMVSS 1 :** NR

**FMVSS 2 :** NR

**Description of the Safety Risk :** According to Ricon, if the position input cam fails and the lift operator continues to press the "up" button on the operating pendant while the lift is occupied, the cutoff switch is disabled and the platform can travel past the vehicle floor height, potentially

**Description of the Cause :** According to Ricon, the cause of the break in the cam has not been determined.

**Identification of Any Warning that can Occur :** NR

**Supplier Identification :****Component Manufacturer**

Name : Ricon Corporation  
Address : 1135 Aviation Place  
San Fernando CALIFORNIA 91340  
Country : United States

**Chronology :**

By email received February 8, 2019, Supreme Corporation was advised by NHTSA that Ricon determined that certain Ricon S and K series wheelchair lifts have a safety-related defect and that Ricon had filed a safety recall report on June 21, 2018 (recall 18E-044). At that point in time, Supreme had not received notification of this equipment recall from Ricon.

On February 11, 2019, Supreme contacted Ricon, requesting serial numbers for lifts Ricon supplied to Supreme that are included in recall 18E-044, to determine whether the affected lifts were included in Supreme's vehicle population.

On February 14, 2019, Supreme again contacted Ricon and requested serial numbers for lifts affected by the recall that were supplied to Supreme.

On February 15, 2019, Supreme received from Ricon the list of the 20 lifts affected by the recall that were supplied to Supreme. The 20 vehicles affected were identified the same day.

On February 25, 2019, the Wabash National Product Safety Council convened and determined that a safety-related defect exists in vehicles equipped with the affected Ricon lifts.

On March 1, 2019, Supreme submitted its 573 safety recall report.

**Description of Remedy :**

Description of Remedy Program : Owners will be directed to Ricon customer service to coordinate replacement of the lift positioning input cam at no charge.

How Remedy Component Differs from Recalled Component : NR

Identify How/When Recall Condition was Corrected in Production : NR

**Recall Schedule :**

Description of Recall Schedule : NR

Planned Dealer Notification Date : MAR 30, 2019 - MAR 30, 2019

Planned Owner Notification Date : APR 15, 2019 - APR 15, 2019

\* NR - Not Reported